

Starter kit accessories DLS/FLS

Part No. 500590



The Starter Kit accessories from Dimetix AG help you to become familiarised with DLS/FLS Distance Laser Sensors. The kit includes all necessary components to operate a DLS/FLS sensor.

Contents

- 1 RS-232 configuration cable (500200) for connecting the DLS/FLS sensor to a PC via an RS-232 serial interface
- 1 Power supply with worldwide usage possible due to wide range input - 100 to 240 VAC - and primary plug system
- 1 CD-ROM with DIMETIX utility software
- 1 DLS/FLS manual

!!!DLS/FLS Laser Distance Sensor must be ordered separately!!!

System requirements

- PC system software must support .NET Framework
- RS-232 serial interface
- In case of only a USB interface on the PC, use the USB/RS-232 converter (500209)

Order information

Part No.	Description
500590	<p>Starter kit accessories DLS/FLS</p> <p>Consisting of:</p> <ul style="list-style-type: none"> - RS-232 configuration cable (500200) - Power Supply IN: 100 ... 240 VAC, 0.6A Out: 24 VDC, 0.75 A → Not applicable for measuring devices with the heater! - DLS/FLS Utility Software - DLS/FLS Manual <p>!!!DLS/FLS Laser Distance Sensor must be ordered separately!!!</p>

